



Better Sound Limited

31 Cathcart Street, London, NW5 3BJ
Phone: 020- 7482 0177 Fax: 020- 7482 2677 e-mail: admin@bettersound.co.uk

Enhanced Equipment Cleaning Procedures March 2020

Mic capsules e.g. lapels, dynamic (NOT condenser)

Extract capsule from mic grill if necessary
Keep capsule facing downwards to minimise liquids entering the capsule
Swirl in distilled water to clean
Shake off excess water and allow to dry
Dip in IPA solution for 20 seconds and shake off excess
If mic head is visibly dirty use toothbrush dipped in IPA and scrub
Leave to dry

Condenser mic capsule only

Extract capsule from mic grill if necessary
Keep capsule facing downwards to minimise liquids entering the capsule
Use toothbrush dipped in IPA and scrub
Leave to dry

Metal Mic Grills

Immerse in hot water and detergent
Scrub grills with small brush e.g. toothbrush
Rinse in clean hot water
Shake off excess water and allow to dry
Dip in IPA solution (20 seconds), shake off excess and allow to dry

Foam Gags & Foam Grill Inserts

Remove from microphone / grill and wash in hot water and detergent
Rinse in clean hot water
Shake off excess water and allow to dry

General Equipment Surfaces and Cables

Wipe down with IPA impregnated paper towel or cloth
If particularly dirty first use a paper towel that has been dipped in mild detergent & hot water or multi-purpose cleaner again applied by paper towel. Do not spray directly on surface to be cleaned.

Phonak In-Ear RX

Dispose of the green wax guard
Clean the Earpiece's entire surface with Bioguard cleaning spray and leave wet for 3 minutes. Do not use any tool or strong detergent
Allow to dry
Wipe down with IPA impregnated paper towel or cloth
Replace the green wax guard with new item
Allow to dry

Headphones, D-shells

Wipe down with IPA impregnated paper towel or cloth
If particularly dirty first use a paper towel that has been sprayed with multi-purpose cleaner. Do not spray directly on surface to be cleaned.

Curly acoustic tubes / Coverts

Dispose of rubber tip
Wipe down tubing and plastic with IPA impregnated paper towel or cloth
Do not get any moisture in to the tube
Fit new rubber tip